

# Make your maintenance easier

# CONCEPT

- · Fast and easy removal of foam from the gripper
- Easy to install on existing gripper(s)
- · Reduces maintenance time and cost
- · No adhesive to remove at foam change

# BENEFITS

- Easy access to the gripper for maintenance and cleaning
- · Can be removed/replaced an unlimited number of times
- · Independant filter for dusty environments

### EASY TO ADAPT

- · Adaptable to all brands of existing grippers
- $\cdot$  All foam styles / brands
- Easily clean and replace the filter by removing the magnetic foam



Adaptable to all kind of foams
All foam grippers









Click here or flash the QR to watch the How-To videos

# **HOW-TO INSTALL**

# First Installation: Magnet Plate

### Step 1


Remove the old foam.


### Step 2

Clean gripper's bottom plate if possible.

Residual adhesive is not an issue and solvents should not be used to remove it.

Scraping the residual adhesive may cause adhesive to be pushed into the valves causing issues not correctable with simple cleaning.





to Gripper

Principle of complete Installation Exploded View

Pull off protection sheet from the magnet's adhesive.

#### Step 4

Apply magnet on bottom side while making sure holes align with gripper's holes.

### Foam Installation / Replacement on Magnet Plate

### Step 1

Remove the old foam.


Roll the foam and start applying on the magnet plate from one side while making sure foam corners' align with the magnet corner stoppers'.

#### Step 3

Unroll the foam completly against the magnet making sure opposite corners fit with the corresponding magnet corner stopppers'.

#### Step 4

Pick a non-porous plate a few second to avoid any risk of leakage.



#### **OPTIONS**



For dusty environments or product, we propose filter to prevent particles from cloqqing your gripper. With the magnetic foam, no special attachment is needed. Place the filter directly between the foam and the gripper. Easily clean or replace the filter by removing the magnetic foam from the gripper.

### Europe

17 avenue des Grenots 91150 ETAMPES - FRANCE

Tél. +33 (0)1 69 92 16 16 Fax +33 (0)1 64 94 21 35



### USA

2551 HWY 70 SW - HICKORY NC-28602

Phone: +(1)828 327 2290 Fax. +(1)828 327 8678



