

Protos® 3400 (X)

The modular measuring system for pH, conductivity and oxygen, for application in hazardous and safe areas.



This device will help you realize considerable savings

The perfectly designed Protos® 3400 (X) measuring system is based on a modular hardware and software concept for liquid analysis and offers flexible solutions precisely tailored to the measuring task. It is also possible to easily measure several process variables such as pH/Cond, pH/pH, Cond/Oxy etc. with the appropriate configuration. The device is fitted with 3 slots and, similar to a PC, it can be simply retro-fitted or modified at any time.

With all these advantages, the Protos® 3400 (X) offers a previously unknown level of functionality and reliability, and with an extraordinarily high level of user comfort.

A razor-sharp display guarantees superb legibility in the most diverse of light conditions. The integrated SMARTMEDIA card allows for the trouble-free saving of configurations, software updates, and measurement data.

The hygienic stainless steel enclosure is ideal for applications in:

- biotechnology
- the pharmaceutical industry
- the food industry

The sturdy, corrosion-resistant, coated steel enclosure stands up well to harsh industrial environments.

For applications in:

- the chemical industry
- the paper industry
- power station engineering
- water/wastewater technology

The Protos® 3400 (X) can easily be integrated into PROFIBUS PA or FOUNDATION Fieldbus networks.

The measuring system also supports all common analog and digital sensors.

Warranty 3 years!

Warranty

Defects occurring within 3 years from delivery date shall be remedied free of charge at our plant (carriage and insurance paid by sender).
Sensors and accessories: 1 year

Facts

- Protos® 3400 (X) S: tightly sealed stainless steel enclosure with hygienic design
- Protos® 3400 (X) C: sturdy, corrosion-resistant coated steel enclosure
- plain-text user interface according to NAMUR – simple and intuitive
- great flexibility provided by modular technology
- modular hardware and software concept permits retrofitting at any time
- 5 process variables simultaneously
- SMARTMEDIA card for saving and transmission of parameter settings, software updates, and measuring data
- high-resolution, transreflective display, white backlighting
- perfect legibility in all light conditions
- operator guidance icon-led
- 6 languages as standard
- global usability thanks to VariPower® power supply, 20 ... 265 V AC/DC
- measuring circuits, galvanically isolated
- 2 current outputs and 4 relay contacts in the basic model
- 2-channel measurement recorder, time and event-controlled, with increased resolution on quick changes
- parameter-set switchover, also remotely
- HOLD function, can be remote-controlled
- KI recorder detects abnormalities in processes
- Sensocheck® sensor monitoring
- connection possibilities for almost all typical analog and digital sensors available in the world
- optional ComFu® wireless set for wireless data transmission
- ServiceScope® – noise level monitoring of the pH input
- sensor network diagram – synchroptic representation of the sensor data
- sensor wear monitor
- sensor load matrix
- adaptive calibration timer – automatic standardization
- lightning protection
- explosion protection: II 2(1) GD Ex me ib [ia] IIC T4 T 70 °C
- control of the fully automatic Unical® 9000 (X) calibration system
- control of the fully automatic Unclean® 900 (X) cleaning system
- PROFIBUS PA
- FOUNDATION Fieldbus
- 3-year warranty



Process Analysis Systems

SMARTMEDIA



Everything on one card

The SMARTMEDIA card, measuring only 4.5 by 3.7 cm and being 1 mm thick, is an extremely compact memory expansion medium available for the Protos® system. The SMARTMEDIA card be connected via the very inexpensive, generally available adapter to RS 232 C, USB etc. or directly via a PCMCIA adapter to any PC.

For software updates and software functions

- contains the complete Protos® software
- software functions can be installed at a later date and activated via transaction numbers (TAN)
- software updates to keep Protos® upgraded with the latest software – even on site

For parameters and the recording of data

- 5 parameter sets can be filed and loaded into the device
- A parameter set contains all parameter data, facilitating rapid exchange and speedy complete parameter setting. Simple return to factory settings

- almost unlimited expansion of the measurement recorder
- Parameter sets can be transmitted from one device to another. This removes the need for the tiresome repetition of inputting parameters.
- The device parameters can be completely saved on a SMARTMEDIA card and then archived directly or on a PC
- extended logbook
- "Electronic Records" and "Electronic Signatures" according to directive FDA 21 CFR, Part 11

SMARTMEDIA is a registered trademark of Toshiba Corp., Japan



Simple operation: Simply insert the SMARTMEDIA card into the small slot on the rear of the front door.

The Functions

Progress in perfection

Alongside outstanding features like the universal VariPower® power supply 20 ... 265 V / AC/DC, the time- and event-controlled 2-channel measurement recorder, and Sensocheck® sensor monitoring, the Protos® 3400 system shines with further pioneering functions:

Early alarm detection with the KI recorder

The KI recorder follows the course of the process and releases a messages in the event of a deviation. The monitoring is always carried out for the primary measured variable, e.g. pH or conductivity and at the same time the temperature. The visualization is graphical with process and limit value variation for both variables.

Checking batch processes with the KI recorder


The KI recorder records the course of a batch (self-teaching function). All further batches are then monitored for deviations from the saved course.

Sensor network diagram for pH measurement


Graphical representation of current sensor parameters in a network diagram on the display – with slope, zero, reference impedance, glass impedance, response time, calibration timer, sensor wear.

ServiceScope®


This function monitors the pH input signal and checks whether it remains in the control range. Moreover, the representation of the noise level over time allows the distinction to be made between individual disturbances, periodic and broadband disturbances, which is helpful for troubleshooting. In this way, it is possible to simply detect regularly recurring disturbances, e.g. large consumers which are regularly switched on or off. An error message is generated if the noise level exceeds the failure limit.



KI recorder



Sensor network diagram



ServiceScope®



Process Analysis Systems

Modules

Universally interchangeable

Various user-defined plug-in measuring modules for measurement and control functions can be combined depending on the measuring task. They also facilitate subsequent trouble-free expansion or modification.

Communication modules for functional expansion: In addition to the OUT module for the expansion of the output options already available as standard, other modules are also available, including modules for PROFIBUS and FOUNDATION Fieldbus.

Combined with the PHU or FIU measuring and control module, Unical® 9000 (X) / Uniclean® 900 (X), and a retractable probe such as Ceramat® WA 150 or SensoGate® WA 130, the Protos® 3400 (X) becomes a fully automatic remote-controlled calibration and cleaning system.


If necessary, it can also record several measurement parameters in any combination with a one device; pH/pH, Cond/Cond etc. and it allows simultaneous pH and conductivity measurement with analog or digital sensors such as Memosens®.



Combined evaluation – i.e. the calculation of several measuring parameters e.g. for differential measurement or quasi-redundant measuring systems. Up to 3 measuring modules can be combined.

Plug & Play – the modules are simply clicked into place in the slots provided, in any order; the modules are automatically recognized; very straightforward retrofitting or modification; hot-swap technology.

Control module for convenient PID control. Analog and digital outputs as well as limit monitoring.



Modules – continued

PH measuring modules

Input module for pH measurement with glass electrodes, ISFET and enamel sensors.

Simultaneous measurement of pH value, ORP, and temperature, also with ISM sensors (Intelligent Sensor Management) and Memosens® sensors.

- Sensocheck® monitoring of glass and reference electrode
- sensor monitor
- sensor wear monitor
- sensor load matrix
- sensor network diagram
- ServiceScope® noise level monitoring of the pH input
- adaptive calibration timer
- timer for sensor checking
- Calimatic® automatic calibration
- KI recorder

COND measuring module

Input module for measuring conductivity with 2- or 4-electrode sensors. Simultaneous measurement of electrical conductivity, resistivity, concentration, salinity, and temperature.

- large measuring range with 2-electrode sensors due to special measuring process
- Sensocheck® polarization detection and monitoring of cable capacitance
- sensor monitor
- USB ultrapure-water monitoring in the pharmaceutical industry

CONDI measuring module

Input module for conductivity measurement with commercial electrodeless sensors.

Simultaneous measurement of electrical conductivity, resistivity, concentration, salinity, and temperature.

- Sensocheck® sensor monitoring
- sensor monitor
- Universal application with many commercial electrodeless conductivity sensors. Adaptation via sensor ID

OXY measuring modules


Input module for measuring oxygen in liquids. Simultaneous measurement of oxygen partial pressure, barometric pressure, and temperature, also with ISM sensors (Intelligent Sensor Management). Calculation of oxygen saturation and concentration. For standard applications and trace measurements in both aqueous media and gases.

- Sensocheck® sensor monitoring – monitoring of the membrane and electrolyte
- sensor monitor
- sensor wear monitor
- sensor load matrix
- automatic correction of barometric pressure influence
- also suitable for trace-oxygen measurement in the ppb range
- external pressure correction

PHU measurement and control module

Activation of the fully automatic Unical® 9000 (X) / Uniclean® 900 (X) measurement, cleaning, and calibration system.

- integrated pH measurement input
- manual, interval- and time-controlled start of calibration and rinsing programs
- 8 programs available



Process Analysis Systems

Communication Modules

OUT communication module

General output module for the expansion of outputs available as standard.

- 4 freely definable electronic relay outputs
- 2 additional passive analog outputs for further process variables

PROFIBUS COMPA communication module

PROFIBUS PA communication unit

- fast, cyclic signal transmission with status
- function block model (PROFIBUS Profile 3.0)
- hazardous-area connection according to the FISCO model
- EDD for SIMATIC PDM

FOUNDATION Fieldbus communication module

Expansion for bus-capable field device

- fast, cyclic signal transmission with status
- function block model
- hazardous-area connection according to the FISCO model
- EDD for AMS

PID controller module

Convenient PID controller.

- continuous controller for the actuation of control valves
- quasi-continuous pulse length/pulse frequency controller for the actuation of straightway valves or metering pumps
- 2 free limit-value contacts, e.g. for three-point control of secondary control processes


FIU digital module

Enables connection of intelligent digital Memosens® sensors and Unical® 9000 (X) / Uniclean® 900 (X) for controlling sensor lock-gates. Supports wireless transmission of measurement data (ComFu®).

- 2 Memosens® sensors can be operated simultaneously

MS digital module

Connection of a Memosens® sensor. Also with a current input and a relay input, e.g. for monitoring equipment.



ProgaLog 3000

PC software for offline parameter setting and documentation of Protos® process analysis systems.



ProgaLog 3000, the PC-based tool for simple offline parameter setting of the Protos® process analysis system. The software enables comprehensive parameter setting, even of multi-channel Protos® systems, and beyond this of a complete Unical®/ Uniclean® system. It includes complete program flows for a fully automatic pH measurement system, including a cleaning program and automatic calibration and control of the sensor lock-gate. Despite these complex parameter options, the interface of the ProgaLog software is well-structured and easy to handle.

Convenient operation

Explorer-style display of the device configuration to keep track of and set up hardware options in self-explanatory fashion.

- graphical user interface for tabular lists of parameters and parameter values
- use of the familiar terms from the Protos® measuring system in the selected language
- program interface in German or English
- entry of Protos® hardware configuration either manually or read from a saved configuration

Value ranges of parameters, their interdependencies and implications of divergent hardware and software versions are observed.

- image display of the individual modules, accurate in every detail down to representation of the terminal assignments.
- intuitive operation
- graphic illustration of complete cleaning and calibration processes of a Unical® system with optional live tracking in a diagram


Easy parameter setting

The parameters of the Protos® process analysis system set on the PC are transferred simply to the Protos® device with a SMARTMEDIA card. In this way, „cloning“ – i.e. identical parameter setting for several Protos® systems – is possible with a minimum effort. Conversely, an existing Protos® configuration can naturally be read

into a PC for further editing and documentation with a SMARTMEDIA card. It is possible to save the configuration there as a data record, print it out, or edit it further and later write it back into the Protos® system.








Complete documentation








Conversion of the complete configuration into Excel or PDF format is done at the press of a button. This makes complete documentation and archiving of the data records very simple; the option to print also allows for archiving in paper form. ProgaLog 3000 runs on all modern Windows operating systems and can be installed and operated simply without administrator rights.



Process Analysis Systems


System Overview






Process Analysis Systems


Menu Structure




Innovative Display




Measurement display with two primary values (above) and two secondary displays (below), i.e. 4 measured values can be simultaneously represented on the display.



Clear icon menu; selected icon blinks black/gray.



Example of a message box, e.g. with safety information.



Menu logic based on MS Windows with scroll bar.



Selection of a configuration via pull-down menus.



- transfective LC graphic display (240 x 160 pixels); high resolution and contrast-rich; with half-tone visualization
- optimal legibility even in the most difficult light conditions thanks to white backlighting
- plain-text user interface according to NAMUR – simple and intuitive
- menu texts can be switched to: German, English, French, Italian, Spanish, and Swedish
- menu logic based on Windows standards
- 2 softkeys with context-dependent functionality

Process Analysis Systems

Product Line Protos® 3400

Device		Order No.
Protos® 3400 S	basic unit/polished stainless steel enclosure VariPower® 20 ... 265 V AC/DC power supply	3400 S
Protos® 3400 C	basic unit/coated steel enclosure VariPower® 20 ... 265 V AC/DC power supply	3400 C
Measuring modules		
PH 3400-032 measuring module	pH module	PH 3400-032
PH 3400-033 measuring module	pH module (double high-resistance)	PH 3400-033
PH 3400-035 measuring module	pH module (ISM)	PH 3400-035
COND 3400-041 meas. module	conductivity module	COND 3400-041
CONDI 3400-051 meas. module	electrodeless conductivity module	CONDI 3400-051
OXY 3400-062 meas. module	oxygen module (standard applications)	OXY 3400-062
OXY 3400-063 meas. module	oxygen module (trace measurements)	OXY 3400-063
OXY 3400-065 meas. module	oxygen module (standard applications/ISM)	OXY 3400-065
OXY 3400-066 meas. module	oxygen module (trace measurements/ISM)	OXY 3400-066
OXY 3400-067 meas. module	oxygen module (trace measurements/increased resolution/ISM)	OXY 3400-067
PHU 3400-110 meas. module	Unical® 9000/Uniclean® 900 communication module	PHU 3400-110
FIU 3400-141 digital module	Memosens®, Unical®, Uniclean®, ComFu® module	FIU 3400-141
MS 3400-160 digital module	Memosens® module	MS 3400-160
Communication modules		
OUT 3400-071 output module	output expansion module	OUT 3400-071
PID 3400-121 controller module	PID controller module	PID 3400-121
COMPA 3400-081 PROFIBUS PA module	PROFIBUS PA module	COMPA 3400-081
COMFF 3400-085 FOUNDATION Fieldbus module	FOUNDATION Fieldbus module	COMFF 3400-085
Software		
ProgaLog 3000	configuration and documentation software	SW 3000



Product Line Protos® 3400 X

Device

		Order No.
Protos® 3400 X S/VPW	basic unit/polished stainless steel enclosure VariPower® 85 ... 253 V AC power supply	3400 X S / VPW
Protos® 3400 X S/24 V	basic unit/polished stainless steel enclosure 24 V AC/DC power supply	3400 X S / 24V
Protos® 3400 X C/VPW	basic unit/coated steel enclosure VariPower® 85 ... 253 V AC power supply	3400 X C / VPW
Protos® 3400 X C/24 V	basic unit/coated steel enclosure 24 V AC/DC power supply	3400 X C / 24V

Measuring modules

PH 3400 X-032 meas. module	pH module	PH 3400X-032
PH 3400 X-033 meas. module	pH module (double high-resistance)	PH 3400X-033
PH 3400 X-035 meas. module	pH module (ISM)	PH 3400X-035
COND 3400 X-041 meas. module	conductivity module	COND 3400X-041
CONDI 3400 X-051 meas. module	electrodeless conductivity module	CONDI 3400X-051
OXY 3400 X-062 meas. module	oxygen module (standard applications)	OXY 3400X-062
OXY 3400 X-063 meas. module	oxygen module (trace measurements)	OXY 3400X-063
OXY 3400 X-065 meas. module	oxygen module (standard applications/ISM)	OXY 3400X-065
OXY 3400 X-066 meas. module	oxygen module (trace measurements/ISM)	OXY 3400X-066
OXY 3400 X-067 meas. module	oxygen module (trace measurements/increased resolution/ISM)	OXY 3400X-067
PHU 3400 X-110 module	Unical® 9000 X/Uniclean® 900 X communication module	PHU 3400X-110
FIU 3400X-140 digital module	Memosens®, Unical®, Uniclean® module	FIU 3400X-140
MS 3400X-160 digital module	Memosens® module	MS 3400X-160

Communication modules

OUT 3400X-071 output module	output expansion module	OUT 3400X-071
PID 3400X-121 contr. module	PID controller module	PID 3400X-121
COMPA 3400X-081 PROFIBUS PA module	PROFIBUS PA module	COMPA 3400X-081
COMFF 3400X-085 FOUNDATION Fieldbus module	FOUNDATION Fieldbus module	COMFF 3400X-085

Software


ProgaLog 3000	configuration and documentation software	SW 3000
---------------	--	----------------

Process Analysis Systems

Product Line Protos® 3400 (X)

Accessories		Order No.
Pipe-mount kit		ZU 0544
Panel-mount kit		ZU 0545
Protective hood		ZU 0548
Adapter M20 x 1.5 to NPT 1/2"		ZU 0658
Connector plugs and cables		
VP8 connector plug		ZU 0721
M12 device socket		ZU 0822
VP8-ST cable (both ends with VP socket)	length: 3 m	ZU 0710
	length: 5 m	ZU 0711
	length: 10 m	ZU 0712
Memory expansion		
SMARTMEDIA card (128 MB)		ZU 0543-128
AuditTrail card (replacement)		ZU 0599
Additional functions (SMARTMEDIA card included)		
5 loadable parameter sets		SW 3400-102
Measurement recorder		SW 3400-103
Extended logbook		SW 3400-104
Software update		SW 3400-106
Software downgrade		on request
Electronic data recording and backup according to FDA 21 CFR Part 11		SW 3400-107
Additional functions (SMARTMEDIA card not required)		
KI recorder (pH)		SW 3400-001
Buffer sets, specifiable (pH)		SW 3400-002
ServiceScope® (pH)		SW 3400-004
Tolerance band recorder (pH)		SW 3400-005
Current characteristic definable		SW 3400-006
TC ultrapure water (Cond)		SW 3400-008
Concentration determination (Cond, Condl)		SW 3400-009
Dissolved-oxygen measurement in carbonated beverages (e.g. beer)		SW 3400-011
ISFET functionality for pH 3400 (X)-035 measuring module		SW 3400-012
2nd Memosens® channel		SW 3400-014
Oxygen measurement with FIU 3400-141, FIU 3400 X-140, MS 3400 (X)-160 modules		SW 3400-015
Trace-oxygen measurement with FIU 3400-141, FIU 3400 X-140, MS 3400 (X)-160 modules		SW 3400-016

Product Line – continued



Process Analysis Systems

Device Equipment

● Device status	▲ Buffer sets specifiable	● Activation of SMARTMEDIA card slot
● 2 parameter sets	● Adaptive calibration timer	▲ 5 loadable parameter sets
● ORP measurement (SHE)	● USP function (Cond)	▲ Measurement recorder
● Sensor network diagram	▲ ServiceScope®	▲ Extended logbook
● Calimatic®	▲ Tolerance band recorder	▲ Software update
● Sensocheck®	▲ Current characteristic definable	▲ Dissolved-oxygen measurement in carbonated beverages (e.g. beer)
● VariPower® power supply	● TC ultrapure water (pH)	▲ ISFET functionality
● 2 current outputs	▲ TC ultrapure water (Cond)	▲ "Electronic Records" and "Electronic Signatures" according to directive FDA 21 CFR, Part 11
● 4 relay contacts	▲ Concentration determination	▲ Oxygen measurement with digital modules
▲ KI recorder		▲ Trace-oxygen measurement with digital modules

The functions marked with ● are already installed in the device as standard.

The functions marked with ▲ can either be retrofitted by TAN (Transaction Number) or are available via SMARTMEDIA card in connection with a TAN (see product line, page 348).

Specifications Protos® 3400 (X) S and Protos® 3400 (X) C

Display	LC graphic display, white backlighting	
Resolution	240 x 160 pixels	
Languages	German, English, French, Italian, Spanish, Swedish (Portuguese)	
Keypad	NAMUR keypad, individual keys, no double assignments [meas] [menu] [▼] [▲] [▶] [◀] [enter] [softkey 1] [softkey 2], NAMUR-LEDs red and green	
Logbook	recording of function activations, appearance and disappearance of warning and failure messages, with date and time	
Storage capacity	approx. 50 entries without SMARTMEDIA card, can be read from display and exported via SMARTMEDIA card	
Extended logbook	> 50000 entries, depending on capacity of SMARTMEDIA card	
Measurement recorder	2-channel measurement recorder with marking of events (failure, maintenance request, function check, limit values)	
Recording medium	SMARTMEDIA card	
Recording capacity	> 50000 entries, depending on capacity of SMARTMEDIA card	
Recording	process variables and span selectable	
Recording method	snapshot, min/max. or mean value	
Time base	10 s ... 10 h/pixel	
Zoom function	tenfold zoom in the event of high rate of change	
Sensor monitor	direct display of measured values from sensor for validation	
KI recorder	adaptive representation of process flow with monitoring and signaling of critical process parameters	
Device self-test	testing of RAM, FLASH, EEPROM, display and keypad, records for QM documentation in accordance with ISO 9000	
Clock	real-time clock with date	
Power reserve	approx. 1 year (lithium battery)	
Data retention in case of power failure	parameters and factory settings	> 10 years (EEPROM)
	logbook, statistics, records	> 1 year (lithium battery)
	measurement recorder	SMARTMEDIA card
Module slots	3	
Power supply	24 (-15 %) ... 230 (+15 %) V AC/DC	approx. 10 VA/10 W
Overvoltage category	II	
Protection class	I	
Pollution degree	2 (EN 61010-1)	
Wire cross-section	2.5 mm ²	

Process Analysis Systems

Specifications Protos® 3400 (X) S and Protos® 3400 (X) C – continued

Protection against electric shock	protective separation of all low-voltage circuits from mains to EN 61010
Input OK 1	galvanically separated (OPTO coupler)
Function	switches the device to HOLD mode (function check)
Switching voltage	0 ... 2 V AC/DC inactive 10 ... 30 V AC/DC active
Input OK 2	galvanically separated (OPTO coupler)
Function	START/STOP KI recorder, switchover to second parameter set
Switching voltage	0 ... 2 V AC/DC inactive 10 ... 30 V AC/DC active
Current output I 1	0/4 ... 20 mA (22 mA), max. 10 V, galvanically separated (galv. connected to output I 2)
Load monitoring	error message if load is exceeded
Overtime*)	22 mA in the case of a message
Measurement error ¹⁾	< 0.2 % current value + 0.02 mA
Current source	0.00 ... 22.00 mA
Current output I 2	0/4 ... 20 mA (22 mA), max. 10 V, galvanically separated (galv. connected to output I 1)
Load monitoring	error message if load is exceeded
Overtime*)	22 mA in the case of a message
Measurement error ¹⁾	< 0.2 % current value + 0.02 mA
Current source	0.00 ... 22.00 mA
Switching contacts*)	4 relay contacts K1 ... K4, floating/K1, K2, K3 are connected on one side
Loadability	AC < 30 V/< 3 A, 90 VA DC < 30 V/< 3 A, 90 W
Usage*)	K1 ... K3, user definable as NAMUR maintenance request/function check, limit values, parameter set 2 active, rinsing contact, USP contact, K4 permanently set as alarm contact (NAMUR failure)
EMC	NAMUR NE 21 and EN 61326
Emitted interference	Class B
Immunity to interference	industry
Lightning protection	EN 61000-4-5, Installation Class 2
Nominal operating conditions	ambient temperature -20 ... +55 °C, relative humidity 10 ... 95 %, not condensing power supply 24 (-15 %) ... 230 (+15 %) V AC/DC, frequency AC 45 ... 65 Hz
Transport/Storage temperature	-20 ... +70 °C

Specifications Protos® 3400 (X) S and Protos® 3400 (X) C – continued

Enclosure	Protos® S: stainless steel, polished, 1.4305 Protos® C: coated stainless steel
Assembly	wall mounting/pipe mounting/panel mounting, sealed against panel
Dimensions	see dimension drawings from page 358
Protection	IP 65/NEMA 4 X
Cable glands	5 M20 x 1.5 cable glands
Weight	approx. 3.2 kg plus approx. 150 g per module

^{*)} user-defined

¹⁾ according to IEC 746 Part 1, at nominal operating conditions

Process Analysis Systems



Specifications Protos® 3400 (X) S and Protos® 3400 (X) C – continued

Explosion protection

IECEX: Ex me ib [ia] IIC T4/Ex tD A21 IP54 T 70 °C
 ATEX: II 2(1) G Ex me ib [ia] IIC T4/II 2 D Ex tD A21 IP54 T 70 °C
 FM: NI, Class I, Div 2, GRP A, B, C, D, T4, NIFW
 with AIS connections to Class I, II, III, Div 1, GRP A-G, Entity
 Class I, Zone 1, A Ex me ib [ia] IIC, T4, Entity
 Class I, Zone 2, A Ex nA IIC, T4, NIFW
 CSA: NI, Class I, Div 2, GRP A, B, C, D, with IS circuits extending into Div 1
 AIS, Class I, Zone 1, Ex me ib [ia] IIC T4, Enclosure 4X
 NI, Class I, Zone 2, Ex nA [ia] IIC, Enclosure 4X
 GOST: 2 Ex me ib [ia] IIC T4, applications – explosive zones 1 and 2, indoor and outdoor
 NEPSI: Ex mb ib [ia] IIC T4/DIP A21 T_A, T6

Nominal operating conditions

ambient temperature –20 ... +50 °C, relative humidity 10 ... 95 %, not condensing

Power supply (Ex em IIC)

VPW: 100 (–15 %) ... 230 (+10 %) V AC < 15 VA, 48 ... 62 Hz
 or
 24 V: AC 24 V (–15 %, +10 %) < 15 VA, 48 ... 62 Hz
 DC 24 V (–15 %, +20 %) < 8 W

Overvoltage category

II

Protection class

I

Pollution degree

2 (EN 61010-1)

Wire cross-section

2.5 mm²

Ground wire connection

2.5 mm², screw M4 (EN 61010-1, 6. 5.1.2.)

Protection against electric shock

protective separation of all low-voltage circuits (SELV) from mains by double insulation to EN 61010-1

Input OK 1 (Ex ib IIC)

galvanically isolated (OPTO coupler), galvanic isolation up to 60 V, protective separation through double insulation to EN 61010-1

Function

switches the device to HOLD mode (function check)

Switching voltage

inactive 0 ... 2 V AC/DC
 active 10 ... 30 V AC/DC
 Ex ib IIC U_i = 30 V

Input OK 2 (Ex ib IIC)

galvanically isolated (OPTO coupler)
 galvanic isolation up to 60 V
 protective separation through double insulation to EN 61010-1

Function


START/STOP KI recorder, switchover to second parameter set

Switching voltage

inactive 0 ... 2 V AC/DC
 active 10 ... 30 V AC/DC
 Ex ib IIC U_i = 30 V

Current output I 1 (Ex ib IIC)

0/4... 20 mA (22 mA), max. 10 V,
 galvanically isolated (galvanically connected with output I 2)
 galvanic isolation up to 60 V
 protective separation due to double insulation to EN 61010-1
 Ex ib IIC U_o = 17 V
 I_o = 84 mA
 P_o = 357 mW



Specifications Protos® 3400 (X) S and Protos® 3400 (X) C – continued

Load monitoring	error message if load is exceeded
Overrange*)	22 mA in the case of a message
Measurement error ¹⁾	< 0.2 % current value + 0.02 mA
Current source	0.00 ... 22.00 mA
Current output I 2 (Ex ib IIC)	0/4... 20 mA (22 mA), max. 10 V, galvanically isolated (galvanically connected with output I 1) galvanic isolation up to 60 V protective separation due to double insulation to EN 61010-1 Ex ib IIC $U_o = 17\text{ V}$ $I_o = 84\text{ mA}$ $P_o = 357\text{ mW}$
Load monitoring	error message if load is exceeded
Overrange*)	22 mA in the case of a message
Measurement error ¹⁾	< 0.2 % current value + 0.02 mA
Current source	0.00 ... 22.00 mA
Relay contacts*) (Ex ib IIC)	4 relay contacts K1 ... K4, floating/K1, K2, K3 connected on one side galvanic isolation to 60 V protective separation due to double insulation to EN 61010-1 Ex ib IIC $U_i = 30\text{ V}$ $I_i = 500\text{ mA}$ $P_i = 10\text{ W}$
Usage*)	K1 ... K3, user definable as NAMUR maintenance request/function check, limit values, parameter set 2 active, rinsing contact, USP contact, K4 permanently set as alarm contact (NAMUR failure)

*) user-defined


¹⁾ according to IEC 746 Part 1, at nominal operating conditions

Process Analysis Systems

Contact Assignments


Protos® 3400

20 ... 253 V AC




Protos® 3400 X VPW

100 ... 253 V AC



Protos® 3400 X 24 V

24 V AC/DC



Mounting Assemblies

ZU 0544 pipe-mount kit

For assembly on vertical or horizontal pipes or posts.



ZU 0548 protective hood

Additional protection from direct weather exposure and mechanical damage.



ZU 0545 panel-mount kit


For assembly in standardized panel cutout 144 x 194 mm.




Process Analysis Systems

Dimension Drawings


Front view




Side view



Back view






Cable glands
M20 x 1.5




Dimension Drawings – continued

ZU 0544 pipe-mount kit





Wall mounting



Process Analysis Systems


Dimension Drawings – continued

ZU 0548 protective hood



Dimension Drawings – continued

ZU 0545 panel-mount kit



Process Analysis Systems

Specifications pH 3400 (X)-032 module

pH/ORP input**) (Ex ia IIC)	simultaneous pH and ORP measurement integrated pH isolation amplifier, coupling capacitance < 100 pF
Measuring range (MR)	pH value -2.00 ... 16.00 ORP value -2000 ... 2000 mV rH value 0.0 ... 42.5
Permissible voltage	ORP and pH [mV] 2000 mV
Permissible cable capacitance	< 2 nF
Glass electrode input ¹⁾	input resistance > 1 x 10 ¹² ohms input current ⁴⁾ < 1 x 10 ⁻¹² A impedance range 0.5 ... 1000 Mohms
Reference electrode input ¹⁾	input resistance > 1 x 10 ¹⁰ ohms input current ⁴⁾ < 1 x 10 ⁻¹⁰ A impedance range 0.5 ... 200 kohms
Measurement error ^{1,2,3)} (Display)	pH value < 0.02 TC: 0.001 pH/K ORP value < 1 mV TC: 0.05 mV/K
Temperature input (Ex ia IIC)	Pt 100 / Pt 1000 / NTC 8.55 kohms / NTC 30 kohms*) 3-wire connection, adjustable
Measuring range	-20 ... +150 °C (Pt 100 / Pt 1000 / NTC 30 kohms) -10 ... +130 °C (NTC 8.55 kohms, Mitsubishi)
Resolution	0.1 °C
Measurement error ^{1,2,3)}	0.2 % meas. val. + 0.5 K (< 1 K with NTC > 100 °C)
ORP*)	automatic conversion to standard hydrogen electrode when type of reference electrode is entered
Sensocheck®	automatic monitoring of glass and reference electrode, message can be switched off
ServiceScope®*) (SW 3400-004)	noise level monitoring of the pH input signal, representation on display
Sensoface®	provides information on the sensor condition, zero/slope, response time, calibration interval, Sensocheck®, can be switched off
Adaptive calibration timer*)	automatic adjustment of calibration interval (Sensoface® message), depending on process variables
Sensor network diagram	graphical representation of the current sensor parameters in a network diagram on the display; slope, zero, reference impedance, glass impedance, response time, calibration timer
Sensor monitor	display of primary measured values from sensor for validation pH input/ORP input/glass el. impedance/ref. el. impedance/RTD/temperature
KI recorder (SW 3400-001)	adaptive representation of process flow with monitoring and signaling of critical process parameters
Tolerance band recorder (SW 3400-005)	registers zero and slope of the electrode and the selected tolerance bands, graphical representation

Specifications pH 3400 (X)-032 module – continued

Sensor standardization*)

operating modes:
 1-/2-/3-point calibration (best-fit line)
 – Calimatic® automatic buffer recognition
 – input of individual buffer values
 – stability criteria can be set
 – product calibration
 – data entry of premeasured electrodes

Drift check*)
 (stability criterion)
 interruptible

fine: 1.2 mV/min (abort after 180 sec)
 standard: 2.4 mV/min (abort after 120 sec)
 coarse: 3.75 mV/min (abort after 90 sec)

Calimatic® buffer sets*)

fixed buffer sets:
 Knick/Mettler Toledo: 2.00/4.01/7.00/9.21
 Merck/Riedel: 2.00/4.00/7.00/9.00/12.00
 DIN 19267: 1.09/4.65/6.79/9.23/12.75
 NIST standard: 1.680/4.008/6.865/9.184
 Techn. buffers to NIST: 1.68/4.00/7.00/10.01/12.46
 Hamilton A: 2.00/4.01/7.00/9.00/11.00
 Hamilton B: 2.00/4.01/6.00/9.00/11.00
 Kraft: 2.00/4.00/7.00/9.00/11.00
 HACH: 4.01/7.00/10.00
 Ciba (94): 2.06/4.00/7.00/10.00
 Reagecon: 2.00/4.00/7.00/9.00/12.00

– manually enterable buffer set with max. three buffer tables
 – buffer set loadable from SMARTMEDIA card
 (SW 3400-002)

Nom. zero*)

pH 0 ... 14, permissible span $\Delta\text{pH} = \pm 1$

Nom. slope*)

25 ... 61 mV/pH (25 °C), permissible span 80 ... 103 %

Zero adjustment

–200 ... 200 mV (for ISFET)

ORP

automatic conversion to standard hydrogen electrode SHE when type of reference electrode is entered

ORP sensor standardization
 (drift check)

zero adjustable from –200 ... 200 mV

V_{iso} *)

–1000 ... 1000 mV

Calibration record/statistics

recording of: zero, slope, V_{iso} , response time, calibration method with date and time of the last three calibrations and the first calibration

Temperature compensation
 media-related

reference temperature 25 °C
 – linear temperature coefficient, user-defined –19.00 ... 19.99 %/K
 – ultrapure water 0 ... 120 °C
 – table 0 ... 95 °C, user-defined in 5-K steps

Power output

for operating the ISFET adapter ZU 0582/0583 for operation of the SE 545 sensor
 +3 V/0.5 mA ($U_o = 2.9 \dots 3.1 \text{ V}/R_i = 360 \text{ ohms}$)
 –3 V/0.5 mA ($U_o = -3.5 \dots -3.0 \text{ V}/R_i = 360 \text{ ohms}$)

Process Analysis Systems

Specifications pH 3400 (X)-032 module

Explosion protection	<p>IECEX: Ex ib [ia] IIC T4</p> <p>ATEX: II 2 (1) G Ex ib [ia] IIC T4</p> <p>FM: IS, Class 1, Div 1, GRP A, B, C, D, T4, Entity Class I, Zone 1, A Ex ib [ia], GRP IIC, T4</p> <p>CSA: NI, Class I, Div 2, GRP A, B, C, D, with IS circuits extending into Div 1 AIS, Class I, Zone 1, Ex ib [ia] IIC T4 NI, Class I, Zone 2, Ex nA [ia] IIC</p> <p>GOST: 1 Ex ib [ia] IIC T4</p> <p>NEPSI: Ex ib [ia] IIC T4</p>
EMC	NAMUR NE 21 and EN 61326
Emitted interference	Class B
Immunity to interference	Industry
Lightning protection	EN 61000-4-5, Installation Class 2
Nominal operating conditions	<p>ambient temperature: -20 ... +55 °C (hazardous areas: max 50 °C)</p> <p>relative humidity: 10 ... 95 % not condensing</p>
Transport/Storage temperature	-20 ... +70 °C
Module enclosure	material: PC/ABS blend
Color	black
Protection	IP 20
Dimensions (mm)	w x h x d: 118 x 91 x 21
Terminals	screw clamp connection, single wires and flexible leads up to 2.5 mm ²

¹⁾ to IEC 746 Part 1, at nominal operating conditions

²⁾ ± 1 count

³⁾ plus sensor error

⁴⁾ at 20 °C, doubles every 10 K

^{*)} user-defined

^{**)} pH/ORP input, ISFET supply voltage, temperature input galvanically connected, galvanically isolated up to 60 V against the other inputs, outputs, relay contacts (protective separation due to double insulation in accordance with EN 61010-1). Ex ia IIC: galvanic isolation up to 60 V.